



Mini Snow Blower

Operation and Maintenance Manual



Skid Pro
PO Box 982
Alexandria, MN 56308
Toll Free: 877-378-4642
www.skidpro.com

Contents

INTRODUCTION	3
To the Purchaser	3
Illustrations	3
Direction Reference	3
Serial Plate	3
SAFETY PRECAUTIONS	4
Before Operation	4
<i>Children</i>	4
<i>Notice</i>	5
Safety Precautions – Snow Blower	5
SNOW BLOWER OPERATION	6
THE SKID STEER	7
General Information	7
Operating the Skid Steer	7
During Operation	8
Roll-Over Protective Structure (ROPS) During Operation	8
MAINTENANCE	9
TRANSPORTING	10
STORAGE	10
OPERATION	11
General Preparation	11
Engine Speed	11
Increasing Traction and Stability	11
Engaging the Drive Mechanism	11
Deflector Adjustment if Manual	Error! Bookmark not defined.
Skid Shoe Adjustment	12
Snow Removal Methods	13
Lubrication	14
PARTS	14
SKID STEER SNOW BLOWER HOSE ROUTING	21
Snow Blower Hose List	22
SKID STEER PLUG WIRING PINS	23
Diagram for Bobcat Machines	23
WIRING GUIDE	25
Wire Hook Up to Quick Disconnect	25
Switch Kit	25

TORQUE SPECIFICATION TABLE.....27
 General Specification Table..... 27
SKID PRO ATTACHMENT Warranty28

INTRODUCTION

To the Purchaser

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. Read and understand this manual before operation.

This manual has been prepared to assist the owner and operators in the safe operation and suitable maintenance of the equipment. The information was applicable to products at the time of manufacture and does not include modifications made afterwards.

Read and understand this operator's manual before attempting to put equipment into service. Familiarize yourself with the operating instructions and all the safety recommendations contained in this manual and those labeled on the equipment and on the skid steer. Follow the safety recommendations and make sure that those with whom you work follow them.


Illustrations

The illustrations may not necessarily reproduce the full detail and the exact shape of the parts or depict the actual models, but are intended for reference only.

Direction Reference

All references to right and left, forward or rearward, are from the operator's seat, facing the steering wheel.

Serial Plate



SKID STEER

IMPLEMENT

MODEL: _____

SERIAL NUMBER: _____

DATE OF PURCHASE: _____

DEALER NAME: _____

SAFETY PRECAUTIONS



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.



DANGER: Indicates an immediate hazardous situation which, if not avoided, will result in death or serious injury.



WARNING: Indicates a potentially hazardous situation which, if not avoided, will result in death or serious injury.



CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

IMPORTANT: Indicates that equipment or property damage could result if instructions are not followed.

NOTE: Gives helpful information.

All products are designed to give safe, dependable service if they are operated and maintained according to instructions. **Read and understand this manual before operation.** It is the owner's responsibility to be certain anyone operating this product reads this manual, and all other applicable manuals to become familiar with this equipment and all safety precautions. Failure to do so could result in serious personal injury or equipment damage. If you have any questions, consult your dealer.

Before Operation

Children

Tragic accidents can occur if the operator is not alert to the presence of children. Children are generally attracted to machines and work being done. Never assume children will remain where you last saw them.

1. Keep children out of the operating area and under the watchful eye of another responsible adult.
2. Be alert and turn machine off if children enter the work area.
3. Before and when backing, look behind for small children.
4. Never carry children while operating the machine. They may fall off and be seriously injured or interfere with the safe operation of the machine.
5. Never allow children to play on the machine or attachment even when they are turned off.
6. Never allow children to operate the machine even under adult supervision.
7. Use extra care when approaching blind corners, shrubs, trees, or other obstructions that might hide children from sight.

Notice

A safe operator is the best assurance against accidents. All operators, no matter how experienced they may be, should read this operator's manual and all other related manuals before attempting to operate the equipment. Please read the following section and pay particular attention to all safety recommendations contained in this manual and those labeled on the equipment and on the skid steer.

Safety Precautions – Mini Snow Blower

1. Read and understand this operator's manual and skid steer operator's manual. Know how to operate all controls and how to stop the unit and disengage the controls quickly.
2. Before attempting to remove obstructions (including plugged wet snow) from the snow blower (i.e. deflector, chute, fan or collector auger areas) always do the following:
 - a. Shut off hydraulics
 - b. Shut off skid steer
 - c. Disconnect hydraulic lines
 - d. Always use another object such as a steel pipe, breaker bar or wooden post to remove object or unplug blower.

NEVER put fingers/hands in the deflector, chute, fan or collector auger area for any reason as this could result in loss of fingers/hands. Failure to follow the above steps could result in loss of fingers/hands or other serious injury!

3. Never wear loose, torn, or bulky clothing around the skid steer and the snow blower. It may catch on moving parts or controls, causing injury.
4. Before and during the snow season, thoroughly inspect the area where the equipment is to be used and remove all objects that may cause damage to the equipment.
5. Set transmission to neutral and disengage clutch, if equipped, before starting the engine.
6. Do not operate equipment in wintertime without wearing adequate winter garments and protective clothing.
7. Never attempt to make any adjustments while engine is running. Read this manual carefully to acquaint yourself with the equipment as well as the skid steer operator's manual. Working with unfamiliar equipment can lead to accidents. Be thoroughly familiar with the controls and proper use of the equipment.
8. Keep all safety guards in place and verify hardware for proper tightening.
9. Check for moving parts excessive wear regularly. Replace worn parts with genuine parts.
10. Replace all missing, illegible, or damaged safety and warning decals. See list of decals in operator's manual.
11. Keep safety decals clean of dirt and grime.
12. Do not modify or alter this equipment or any of its components, any equipment or any of its components or any equipment function without first consulting your dealer.
13. Use of counterweights is recommended. Weights provide the necessary balance to improve stability, traction and steering. Use only those recommended by your dealer.

SNOW BLOWER OPERATION

1. Before leaving the skid steer unattended, take all possible precautions. Park the skid steer/snow blower on level ground, place the transmission in neutral, set the parking brake, disengage the Aux hydraulics, lower the equipment to the ground, place all levers including auxiliary control levers in neutral, shut off the engine and remove the ignition key.
2. Before starting the skid steer/snow blower, remove any ice that has accumulated in the auger/fan.
3. Prior to operation, clear work area of all objects that can be picked up and thrown. Mark all curbs, pipes, etc. that cannot be moved.
4. Be sure the Aux hydraulics switch/lever is in OFF position before starting engine.
5. Exercise extreme caution when operating on or crossing a gravel drive, walks, or roads. Stay alert for hidden hazards or traffic.
6. Do not carry passengers.
7. Adjust skid shoes – housing height to clear gravel or crushed rock surface.
8. Keep clear of rotating parts. Do not put hands or feet under or into snow blower with engine running, and allow the rotating parts to stop BEFORE unclogging the collector/fan housing or chute, and making any repairs, adjustments or inspections. Use only a 36" long piece of wood to unclog blower.
9. Park the skid steer/snow blower on level ground, place the transmission in neutral, set the parking brake, disengage the Aux hydraulics, lower the equipment to the ground, place all control levers in neutral, shut off the engine, remove the ignition key and allow the rotating parts to stop BEFORE unclogging the collector/fan housing or chute, and making any repairs, adjustments or inspections. **Use only a 36" long piece of wood to unclog blower.**
10. If the snow blower starts to vibrate abnormally, disengage the Aux hydraulics, stop the engine immediately and check for cause. Excessive vibration is generally a sign of trouble.
11. Do not run the engine indoors except when starting engine and transporting attachment in or out of building. Carbon monoxide gas is colorless, odorless and deadly.
12. Do not attempt to operate on steep slopes. If operating on slopes is necessary, exercise extreme caution when changing direction.
13. Never operate snow blower without guards, and other safety protective devices in place.
14. Keep clear of chute discharge. This chute has the capability of throwing objects at far distances.
15. Never operate snow blower near glass enclosures, automobiles, window wells, embankments, etc. without proper adjustment of snow discharge angle.
16. Never operate machine at high transport speeds on a slippery surface.
17. Use extra caution when backing up.
18. Do not direct discharge at bystanders or animals. Ejected objects may cause injury.
19. Disengage power to auger/fan when transporting or when not in use.
20. Never operate the snow blower without good visibility and lighting.
21. Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear a suitable hearing device such as earmuffs or earplugs to protect against objectionable or uncomfortable noises.
22. Never allow anyone near the work area.

THE MINI SKID STEER

General Information

1. Read the operator's manual carefully before using skid steer. Lack of operating knowledge can lead to accidents.
2. Do not permit anyone but the operator to ride on the skid steer. There is no safe place for passengers.

Operating the Skid Steer

1. Never run the skid steer engine in a closed building without adequate ventilation, as the exhaust fumes are very dangerous.
2. Adopt safe driving practice: Keep the parking brake on at all times during transportation.
3. Always drive at a safe speed relative to local conditions and ensure that your speed is low enough for an emergency stop to be safe and secure.
4. Reduce speed prior to turns to avoid the risk of overturning. Keep speed to a minimum.
5. Always keep the skid steer in gear to provide engine braking when going downhill. Do not coast.
6. Never allow an open flame near the fuel tank or battery.
7. Make sure the proper shields are installed when using the equipment and always replace the shields if damaged.
8. Park the skid steer/snow blower on level ground, place the transmission in neutral, set the parking brake, disengage the Aux hydraulics, lower the equipment to the ground, place all levers including auxiliary control levers in neutral, shut off the engine and remove the ignition key BEFORE leaving the skid steer.
9. Never park the skid steer on a steep slope.
10. Do not attempt to operate on steep slopes. Avoid sudden uphill turns on steep slopes.
11. Use of counterweights for better traction and stability is recommended.
12. Handle fuel with care, as it is highly flammable.
13. Use approved fuel container.
14. Never add fuel to running engine or a hot engine.
15. Fill fuel tank outdoors with extreme care. Never fill fuel tank indoors. Replace fuel cap securely and wipe up spilled fuel.
16. Never allow anyone to operate the snow blower until they have read the manual completely and are thoroughly familiar with basic skid steer and snow blower operation.
17. Make sure the skid steer is counterweighted as recommended by your dealer. Weights provide the necessary balance to improve stability, traction and steering.
18. Always make sure all snow blower components are properly installed and securely fastened BEFORE operation.
19. Never attempt to start the engine and/or engage snow blower drive while standing beside the skid steer.
20. Always start the engine from the operator's seat with all the transmission lever(s) and snow blower drive lever in neutral.
21. DO NOT bypass the safety system by shorting across the terminals of the starter motor to start the engine. This may cause the skid steer to move suddenly.
22. If the safety start system does not work, consult your dealer immediately.

During Operation

1. Do not allow passengers on the skid steer/snow blower at any time. There is no safe place for passengers on the equipment. The operator **MUST** sit in the skid steer seat.
2. Eye and hearing protection is recommended when operating the snowblower.
3. Operate only during daylight hours, or when the area is well lit with bright artificial light.
4. Park the skid steer/snow blower on level ground, place the transmission in neutral, set the parking brake, disengage the Aux hydraulics, lower the equipment to the ground, place all control levers in neutral, shut off the engine and remove the ignition key **BEFORE** leaving the operator's seat.
5. Inspect the snow blower after striking any foreign object to assure that all snow blower parts are safe and secure and not damaged.
6. Be especially observant of the operating area and terrain. Watch for holes, rocks, or other hidden hazards. **ALWAYS** inspect the area prior to blowing.
7. **DO NOT** blow near the edge of drop-offs or banks.
8. **DO NOT** blow on steep slopes as overturn may result.
9. Operate up and down (not across) intermediate slopes. Avoid sudden starts and stops.
10. Drive skid steer backwards up steeper slopes with blower off. Then blow as you travel down the slope.
11. Slow down before you change directions on any slope.
12. Use wheel weights on your skid steer to increase stability on slopes.
13. Never stand alongside of the unit while the engine is running.

Roll-Over Protective Structure (ROPS) During Operation

1. **DO NOT** weld, drill or alter the ROPS. Damaged ROPS must not be straightened or used. If damage does occur, consult your dealer.
2. If ROPS is lowered or removed from the skid steer for any reason, it must be erected and/or refitted immediately. Original bolts or equivalent replacements must be used and tightened to the correct torque.
3. Your dealer does not recommend usage of skid steer with ROPS removed.
4. Seat belt usage: With ROPS installed on the skid steer it is imperative that the seat belt be installed, used and correctly adjusted, at all times. **DO NOT** use a seat belt if operating without ROPS.
5. Keep all shields and covers in place. All skid steer and equipment shields and covers must be correctly installed at all times. When necessary to remove these, they must be reinstalled immediately.
6. Keep clear of all rotating driveline components. Be especially observant of implement areas of discharge, intake or other mechanical motion.
7. Securely lock equipment drive shaft. Check that all skid steer and equipment drivelines are in good working order.
8. Additional safety equipment: A fire extinguisher and first aid kit should be kept readily accessible. These are available through your dealer.

MAINTENANCE

Always use genuine parts when replacement parts are required during operation.

1. Keep the skid steer and snow blower properly maintained.
2. Park the skid steer/snow blower on level ground, place the transmission in neutral, set the parking brake, disengage the Aux hydraulics, lower the equipment to the ground, place all control levers in neutral, shut off the engine and remove the ignition key and allow the rotating parts to stop BEFORE making any snow blower adjustments.
3. To avoid injury, do not adjust, unclog or service the snow blower with the skid steer engine running. Make sure rotating components have completely stopped before leaving the operator's seat.
4. Keep the skid steer/snow blower clean. Snow and ice build-up can lead to malfunction or personal injury from thawing and refreezing in garage.
5. Always wear eye protection when cleaning or servicing the snow blower.
6. Service the unit in safety: DO NOT service the skid steer while the engine is running or hot, or if the unit is in motion. Always lower snow blower to the ground. If necessary to service unit with blower raised, securely support with stands or suitable blocking before working underneath. Do not rely on hydraulically supported devices for your safety. They can settle suddenly, leak down, or be accidentally lowered.
7. Do not attempt to service machine, clear obstructions or unplug blockages with the engine running. Always shut off engine and allow all motion to cease.
8. The manufacturer will not claim responsibility for fitment of unapproved parts and/or accessories and any damages as a result of their use.
9. Make sure all shields and guards are securely in place following all service, cleaning, or repair work.
10. Do not modify or alter this equipment or any of its components or operating functions. If you have any questions concerning modifications, consult with your dealer.
11. Do not operate a unit which is defective or has missing parts. Make sure that all recommended maintenance procedures are completed before operating the unit.
12. Check all controls regularly and adjust where necessary.
13. Periodically check all nuts and bolts for tightness, especially wheel hub and rim nuts.
14. Snow blower fan and auger must be checked for tightness. Remove any twine, wire, etc. that may have wrapped on the fan or the auger.
15. To avoid serious personal injury: Escaping hydraulic/diesel fluid under pressure can penetrate the skin causing serious injuries. Do not use your hands to check for leaks. Use a piece of cardboard or paper to search for leaks.
16. Stop engine and relieve pressure before connecting lines. Tighten all connections before starting engine or pressurizing lines.

TRANSPORTING

1. Transporting on public roadway: When driving the skid steer and equipment on the road or highway under 25 mph, at night or during the day, use flashing amber warning lights and the Slow Moving Vehicle ("SMV") identification emblem.
2. Check local traffic codes that may apply to unit usage on public roads and highways in your area. The use of flashing amber lights is acceptable in most localities. However, some localities may prohibit their use.
3. Always disengage equipment drive prior to transporting unit.

STORAGE

Before storing the snow blower, certain precautions should be taken to protect it from deterioration.

1. Clean the snow blower throughout.
2. Make all the necessary repairs.
3. Replace all safety signs that are damaged, lost, or otherwise become illegible. If a part to be replaced has a sign on it, obtain a new safety sign from your dealer and install it in the same place as on the removed part.
4. Repaint all parts from which paint has worn or peeled.
5. Lubricate the snow blower as instructed under the "*Lubrication*" section.
6. When the snow blower is dry, oil all moving parts. Apply oil liberally to all surfaces to protect against rust.
7. Store in a dry place.

OPERATION

General Preparation

1. Read the operator's manual carefully before using the skid steer and snow blower. Be thoroughly familiar with the controls and proper use of the equipment. Know how to stop the unit and disengage the controls quickly.
2. Wear adequate winter outer garments while operating the equipment.
3. Make sure the snow blower is clear of snow and other material before engaging the snowblower.
4. Make sure the auger and fan operate freely.
5. Adjust the skid shoes so the snow blower runs leveled.
6. Before engaging the snow blower drive, always have the engine running at idle.
7. Operate the snow blower at maximum to 3/4 engine RPM.

Engine Speed

1. Start the skid steer engine. Let the engine warm up at least one minute before engaging the drive mechanism then increase speed gradually.
2. Make sure the snow blower head is properly positioned and engage the drive mechanism.
3. Adjust the ground speed according to conditions. For maximum power, run engine at or near full throttle.

IMPORTANT:

Use full RPM power when removing wet, sticky snow. Low RPM power will tend to clog the chute.



WARNING:

To avoid serious personal injury: Do not use your hands to unclog the chute. Use a 36" (925mm) stick or board. Do not attempt to unclog the chute while engine is running. If the chute is clogged, shut off the skid steer engine, remove the key and allow the rotating parts to stop before removing the snow from the chute.

Increasing Traction and Stability

The use of approved tire chains and wheel weights is recommended for extra traction and stability, especially when operating in snow and/or on slippery surfaces. See your dealer for details.

Engaging the Drive Mechanism

Refer to the skid steer's operating manual for instructions.



WARNING:

To avoid serious personal injury: Make sure skid steer engine and snow blower come to a complete stop and skid steer drive mechanism is disengaged BEFORE making any adjustments.

Skid Shoe Adjustment

Adjust the skid shoes so that the snow blower runs level and according to the surface conditions so that stones are not thrown with the snow.

Adjust both skid shoes to the same height to keep the cutting-edge level and adjust upwards for smooth surfaces.

Remove skid shoe bolts (item 2) and adjust according to instructions below, and securely tighten bolts:

Clearance between cutting edge and surface:

- Level paved surface: Adjust to 1/16" to 1/8"
- Uneven or gravel surface: Adjust 1/2" to 5/8"

Snow Removal Methods

When removing snow, do not use the snow blower as a dozer blade to push snow. Let the snow blower work its way through deep drifts. If the speed of your skid steer is too fast, the snow blower may become overloaded and clog. For the best results, raise the snow blower and remove a top layer of snow. A second pass with the snow blower will remove the remaining snow.

IMPORTANT:

Use full RPM power when removing wet, sticky snow. Low RPM power will tend to clog the chute.




WARNING:

To avoid serious personal injury: Do not use hands or feet to unclog chute. Do not attempt to clear clogged chute of snow while skid steer engine is running. If the chute clogs, disengage the Aux hydraulics, shut off the skid steer engine, set the parking brake, lower snow blower to the ground, place transmission in neutral, remove the ignition key, wait for all movement to stop, and then clear the snow from the chute.

A definite pattern of operation is required to thoroughly clean the snow area. These patterns will avoid throwing snow in unwanted places as well as eliminating a second removal of snow.

PATTERN 1


DISCHARGE SNOW BOTH SIDES



DISCHARGE SNOW BOTH SIDES

Where it is possible to throw the snow to the left and right (above), as on a long driveway, it is advantageous to start in the middle. Plow from one end to the other, throwing snow to both sides without changing the direction of the discharge guide.


PATTERN 2



DISCHARGE SNOW THIS SIDE ONLY

If the snow can only be thrown to one side of the driveway or sidewalk (above), start on the opposite side. At the end of the first pass, rotate the discharge guide 180 degrees for the return pass. At the end of each succeeding pass, rotate the discharge guide 180 degrees to maintain direction of throw in the same area.

900-01-0001
48" MINI SNOW BLOWER



900-01-0001**48" MINI SNOW BLOWER - PARTS BREAKDOWN**


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	HW-.500-13X1.75G5	1/2"-13 X 1-3/4" GRADE 5 BOLT	8
2	HW-.500FW	1/2" FLAT WASHER	12
3	HW-.500-13NYL	1/2-13 NYLOCK NUT ZINC	8
4	AU-03-1625-1.750	4 BOLT 1.75 FLANGE BEARING	1
5	900-02-0004	48" AUGER ASM	1
6	HW-M12X1.75X25HH	12X1.75X25MM HEX HD 8.8	4
7	900-02-0007	AUGER MOTOR MOUNT	1
8	900-03-0018	48" SQUARE CUTTING EDGE	1
9	HW-.500-13NYLG8	1/2"-13 NYLOCK NUT G8	6
10	HW-.500-13X1.5CBG8	1/2"-13X1.5 CARRIAGE BOLT G8	6
11	900-02-0005	SKID SHOE - LH	1
12	SP-2019-4	SKIDPRO PLACARD	2
13	900-02-0001	48" MINI BLOWER BODY	1
14	AU-03-5114	SPACER	1
15	AU-03-5042	ROTATION SPROCKET	1
16	AU-03-1839	ROTATION GUARD	1
17	900-02-0006	SKID SHOE - RH	1
18	900-02-0003	16" FAN ASM	1
19	900-03-0021	16" FAN RESTRICTOR	1
20	AU-03-1836	CHUTE HOLD-DOWN BRACKET	1
21	AU-03-20056	WIRE-LOCK CLEVIS PIN, SQUARED	2
22	AU-03-1837	CHUTE SPACER	1
*22	AU-03-1837-060	CHUTE SHIM, 060	-
23	AU-02-1757	CHUTE TOP	1
24	HW-.25-20X1.0G5	1/4"-20X1" GRADE 5 BOLT	7
25	HW-.25-20NYL	1/4"-20 NYLOCK NUT	7
26	HW-.250FW	1/4" USS FLAT WASHER	10
27	AU-02-1502-4	CHUTE	1
28	787-02-0003	CII-COMMON IND INTERFACE ASM	1
*28	787-02-0010-ASM	MQT-BOBCAT STYLE QT ASM	-
*DENOTES ALTERNATE OPTION			

900-01-0001

HYDRAULIC COMPONENTS

900-01-0001

HYDRAULIC COMPONENTS





900-01-0001**HYDRAULIC COMPONENTS - PARTS BREAKDOWN**

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	H500-80-10J9012MORB	1/2" X 80" HOSE -10 FJIC90 X -12 MORB	1
2	H500-69-10J12MORB	1/2" X 69" HOSE -10 FJIC X -12 MORB	1
3	AU-03-1775	4 PLUG HARNESS	1
4	HSL500	HOSE SLEEVE	1
5	AU-03-9990-12-12	1/2" FEMALE COUPLER	1
6	AU-03-9991-12-12	1/2" MALE COUPLER	1
7	H-RVPS-10-N-T08TX-30	RELIEF VALVE 2250 PSI	1
8	H500-FT21-10-08	-10 MJIC X -8 MORB ADAPTER	1
9	H500-39-10J10J	1/2" X 39" HOSE -10 FJIC X -10 FJIC	1
10	HW-.375-16X2CB	3/8"-16 X 2" CARRIAGE BOLT	2
11	AU-03-1510	ROTATION MOTOR	1
12	HW-.375USSFW	3/8" FLAT WASHER	5
13	HW-.375LW	3/8" LOCK WASHER	2
14	HW-.375-16NUT	3/8-16 NUT	2
15	H500-6801-6-10	-6 MJIC X -10 MORB 90DEG	2
16	H250-16-6J6J	1/4" X 16" HOSE -6 FJIC X -6 FJIC	2
17	H500-6402-8-10	-8 MORB X -10 FJIC ADAPTER	1
18	H500-12-10J10J	1/2" X 12" HOSE -10 FJIC X -10 FJIC	1
19	AU-03-9032	12 CU/IN MOTOR	1
20	H500-9-10J10J	1/2" X 9" HOSE -10 FJIC X -10 FJIC	1
21	H500-20-10J10J	1/2" X 20" HOSE -10 FJIC X -10 FJIC	1
22	AU-02-3200-900-ASM	MANIFOLD ASSEMBLY - 48" BLOWER	1
23	H500-15-10J10J	1/2" X 14.5" HOSE -10 FJIC X -10 FJIC	1
24	H500-6804-10-10-10	-10 MORB X 2-10 MJIC TEE	1
25	HW-.375-16X1.0G5	3/8"-16X1" HEX BOLT G5	3
26	H750-6400-10-10	ADAPTER -10 MORB X -10MJIC	3
27	AU-03-9030	3.0 CU/IN FAN MOTOR	1
*27	AU-03-9031	4.0 CU/IN FAN MOTOR	--
28	HW-.500-20X1.5FCS	1/2"-20 X 1 1/2" FERRY CAP SCREW	2
29	HW-.375-16NYL	3/8 - 16 NYLOCK NUT	2
30	AU-01-1600	CHUTE TIP CYLINDER	1
31	HW-.375-16X2.0G5	3/8"-16 X 2" GRADE 5 BOLT	2
32	H250-2404-6-4	-6 MJIC X -4 MNPT	2
33	H250-52-6J6J	1/4" X 52" HOSE -6 FJIC X -6 FJIC	1
34	H250-58-6J6J	1/4" X 58" HOSE -6 FJIC X -6 FJIC	1
*DENOTES ALTERNATE OPTION			




AU-02-3200-900-ASM

MANIFOLD ASSEMBLY - 48" BLOWER




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	AU-02-3200	MANIFOLD BLOCK	1
2	H375-FT21-6-6	-6 MJIC X -6 MORB	4
3	H500-6802-10-12	-10 MJIC X -12 MORB 45 DEG	2
4	H750-6801-10-12	-10 MJIC X -12 MORB 90 DEG	2
5	H750-6400-10-12	-10 MJIC X -12 MORB	1
6	H750-6410-16-10	-16 MORB X -10 FORB ADAPTER	1
7	H750-6803-10-10-10	-10 MORB X 2-10 MJIC TEE	1
8	H500-FT17-8	-8 MORB HH PLUG	1

787-02-0010-ASM
MQT-BOBCAT STYLE QT ASM




787-02-0010-ASM

PARTS BREAKDOWN



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	787-02-0004	MQT - BOLT ON	1
2	787-02-0007	MQT - LOCATING BRACKET	2
3	787-03-0035	MQT - BOLT ON SIDE	2
4	HW-.375-16X1.125G8	3/8"-16X1-1/8" GRADE 8	8
5	HW-.375-16NYLG8	3/8"-16 NYLOCK GRADE 8	8
6	HW-.750-10X2.0G8	3/4"-10 X 2" HH G8	8
7	HW-.750-10NYLG8	3/4"-10 NYLOCK NUT G8	8

REMOVE SIDE PLATES AND LOCATE INSIDE
WHEN MOUNTING ON FULL SIZE QT







USE CENTER HOLES TO
STORE UNUSED HARDWARE

787-02-0009-ASM


CII-COMMON IND INTERFACE ASM

ADJUSTABLE IN 1/8" INCREMENTS
SHIPS STANDARD AT 9-1/2"
MAX = 9-1/2" (OUTSIDE HOLES)
MIN = 9" (INSIDE HOLES)



787-02-0009-ASM

PARTS BREAKDOWN



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	787-02-0003	CII QT - BOLT ON	1
2	787-02-0008	CII QT - BOLT ON TOP BAR	1
3	HW-.375-16X1.125G8	3/8"-16X1-1/8" GRADE 8	6
4	HW-.375-16NYLG8	3/8"-16 NYLOCK GRADE 8	6
5	HW-.375 SAE FW G8	3/8" SAE WASHER G8	2
6	HW-.750-10X2.0G8	3/4"-10 X 2" HH G8	6
7	HW-.750-10NYLG8	3/4"-10 NYLOCK NUT G8	6

Always use genuine parts when replacement parts are required.



WARNING: To avoid serious personal injury:

- Before cleaning, adjusting or repairing the snow blower: Bring the skid steer to a complete stop, disengage the Aux hydraulics, apply parking brake, lower the implement to the ground, shut off the engine and remove the ignition key.
- Never park the skid steer inside a building where an open flame or sparks are present. Allow the engine to cool down before storing in any enclosure.
- Run the snow blower a few minutes after blowing snow to prevent freeze up of auger and fan.
- Provide adequate blocking before working under the snow blower when in raised position.

Lubrication

Use oil or grease gun and lubricate as follows:

DESCRIPTION	INTERVAL	LUBRICATION REQUIRED
Bearing	8 hours of operation	Grease each auger bearing.

PARTS

Introduction

All parts are illustrated in "exploded views" which show the individual parts in the normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "*Item No.*" column, and are followed by the description and quantity required. Where "Width" is indicated in the part number, replace it with the width (i.e. 66, 72, 84) of your snow blower.

The manufacturer reserves the right to change, modify, or eliminate from time to time, for technical or other reasons, certain or all data, specifications, or the product or products themselves, without any liability or obligation.

SKID PRO ATTACHMENT Warranty

Attachments covered under this 24 Month Warranty include:

Angle Broom; Backhoe; Industrial Brush Cutters: Close Front, Open Front, Open Front High Flow; Dozer Blade; 84" Industrial Grapple Rake; 72" Grapple Rake; Land Leveler; Pallet Forks; Skid Hitch; Snow Blade; Snow Blower; Soil Conditioner; Stump Bucket; Tiller; Tree Shear;

Skid Pro warrants above attachments for twenty-four months from date of shipment, to the original owner. Warranty covers products to be free from defects in material and workmanship when properly set up and operated in accordance with Skid Pro's recommendations.

WARRANTY CLAIM PROCEDURE

All warranty claims must be submitted within the manufacturer's limited warranty period. Pictures and/or a video of the failing component(s) are required to properly document all potential warranty claims. To submit a warranty claim, contact your Skid Pro Product Guru or complete a [Warranty Claim Form](#) on our website and send it along with supporting pictures/video to sales@skidpro.com. Upon receipt, the warranty claim information will be reviewed and once determined to be a valid claim, a return authorization number will be issued for the return of the defective part(s) if applicable and replacement part(s) will be shipped. If it is determined the defective parts are to be returned and they are not received by Skid Pro within 30 days of receiving the replacement parts, the Buyer will be charged for the cost of the replacement parts plus any shipping charges. Tampering with the failed part (i.e. disassembling a motor or cylinder) will void the warranty.

EXCLUSIONS OF WARRANTY

Skid Pro's requirement for any issue with respect to attachments shall be limited to repairing or replacing the defective part, as this is a parts-only warranty and does not include any labor to replace or install the part or downtime from resulting issue. Skid Pro has full technical support & assistance to assure customer replaces the part properly for optimal performance on attachment.

This warranty shall not apply to any attachment's wear items, or attachments that have been repaired or altered outside the Skid Pro factory in any way, or that has been subject to misuse, negligence or accident beyond Skid Pro's recommended use and/or machine rated capacity.

This warranty is exclusive and in lieu of all other warranties and conditions. Skid Pro disclaims all other warranties and conditions, express or implied, including any implied warranties or conditions of merchantability or fitness for a particular purpose. In no event shall Skid Pro be liable for any special, incidental, indirect or consequential damage, whatsoever, including, but not limited to, loss or interruption of business, lost profits, or loss of machine use, whether based on contract, warranty, tort, negligence, strict liability, statute or otherwise, even if Skid Pro has been advised of the possibility of such damages.

No agent, employee, or representative of Skid Pro has any authority to bind said company to any affirmation, representation, or warranty concerning its machinery and/or attachments except as specifically set forth herein. Any disagreement or dispute of warranty policy or customer expectations of product, soundness, functionality, or performance would take place in Douglas County, Alexandria, MN, where Skid Pro operates.



**PO BOX 982
Alexandria, MN 56308**

**Phone: 877-378-4642
FAX: 320-759-1057
www.skidpro.com
sales@skidpro.com**